


# Automated 24/7 Evaporation



Leading Safety Standards

Superior Ease of Use

Reduced Cost of Ownership

## Operating Instructions

Automatic Module Hei-VAP Distimatic  
Automatic Module Hei-VAP Industrial Distimatic  
Operating instructions must be read before initial start-up. Please follow the safety instructions provided. Please keep for future reference.

 **heidolph**  
research made easy

<b>About this Document</b>	<b>5</b>
Version type .....	5
About this manual .....	5
Purpose and target group .....	6
Configurations.....	6
<b>Safety Instructions</b>	<b>7</b>
Terms and signs used.....	7
General safety instructions .....	10
<b>Device Description</b>	<b>18</b>
Device Description.....	18
<b>Installation</b>	<b>19</b>
Scope of delivery.....	19
Storage and transport .....	21
Unpacking the device.....	21
Overview of the components.....	22
Explanation of the components.....	24
Function and connection principle .....	32
Function principle of Distimatic .....	32
Connection principle of the vacuum circuit (Hei-VAP) .....	33
Connection principle of power supply (Hei-VAP) .....	36
Connection principle of the vacuum circuit (Hei-VAP Industrial).....	37
Connection principle of power supply (Hei-VAP Industrial) .....	39
Installation .....	40
Distimatic in general .....	41
Hei-VAP Distimatic.....	51
Hei-VAP Industrial Distimatic.....	61
Powerbox, multiple socket and control box.....	74
<b>Start-Up</b>	<b>77</b>
Preparatory steps .....	77
Switching the control box on .....	78
Operation .....	78
Operating panel .....	79
Operating states.....	80
Select operational mode .....	80
Setting date and time .....	85
Refill sensor.....	86
Cut-out sensor .....	86

<b>Error Codes</b>	<b>88</b>
<b>Maintenance, Cleaning, Service</b>	<b>91</b>
Maintenance .....	91
Cleaning.....	91
Disassembly .....	93
Disposal .....	94
Contact / Technical Service .....	95
<b>Attachments</b>	<b>96</b>
Technical data .....	96
EC Declaration .....	99
Confirmation of condition of unit.....	100



➤ **Version type**

Description	Version
1.4	09/2014

➤ **About this manual**



Please read this manual carefully and in particular all safety and warning notices. Please ensure that every operator reads this manual.



Please ensure that this manual is accessible for every operator.

For the current version of this operating manual in pdf format, please go to <http://www.heidolph-instruments.com/support/operation-manuals/automatic-module-distimatic>

This manual utilizes symbols which facilitate access to specific information.

The safety instructions are documented in chapter safety instructions. Specific warnings are at the beginning of every chapter.



## ➤ Purpose and target group

This manual describes the function, operation and maintenance of the Automatic Module Distimatic. It is intended for use by trained and authorized personnel only.

Operate according to descriptions in this manual only. If there is something you do not understand, or certain information is missing, ask your manager or contact the manufacturer. Do not do anything without authorization.

## ➤ Configurations

The units are available in different configurations as documented in this manual.



## ➤ Terms and signs used

### Warning notices

In this manual you will find standardized terms and signs to warn you of possible dangers and avoid injury or damage. Kindly obey the signs listed below:

Signal word	Meaning
<b>DANGER</b> 	DANGER indicates a hazardous situation which, if not avoided, will result in death or irreversible injury.
<b>WARNING</b> 	WARNING indicates a hazardous situation which, if not avoided, could result in serious injury or material damage.
<b>CAUTION</b> 	CAUTION indicates a hazardous situation which, if not avoided, may result in a risk of minor injury or material damage.

### Design of warning notices

<b>DANGER</b> 	<b>The type and source of the danger are displayed here!</b>  Here, the possible consequences are described when no measures are taken to prevent dangers occurring. → Here, the measure for risk prevention is specified.
<b>WARNING</b> 	<b>Risk of injury due to failure to observe safety signs and safety instructions!</b>  Dangers emerge when safety signs, located on the device, are not observed or when safety instructions are not followed. → Please note the warning notices.



### Symbols

The following symbols and distinctions in these operating instructions provide information on standard handling instructions:

#### Mandatory signs

Symbol	Description	Symbol	Description
	Please observe this information		Use eye protection
	Please observe the additional information in this document or other documents mentioned		Use hand protection
	Use protective clothing		Use foot protection
	Pull the power plug after use Pull the power plug prior to opening the housing		Use ear protector

#### Warning signs

Symbol	Description	Symbol	Description
	Warning of a dangerous location		Warning of a risk of entanglement
	Warning of a hot surface		Warning of dangerous electric voltage
	Warning of hand injuries		Warning of vacuum
	Warning of automatic start		Warning of slippery conditions
	Warning of explosive materials		Warning of explosion-risk area



### Prohibitory signs

Symbol	Description	Symbol	Description
	Fire, open flame and smoking prohibited		Prohibition for people with metal implants
	Prohibition for persons with a pacemaker		Extinguishing with water is prohibited
	Depositing or storing is prohibited		

#### Other icons and symbols

Symbol	Description
	Handling instructions concerning a user action
	List of information
	List of variants



## ➤ General safety instructions

The device has been constructed according to state-of-the-art technology and recognized safety regulations. However, risks may still arise during installation, operation and maintenance.

→ Please observe the safety instructions and warning notices.

The safety instructions provided in this chapter are supplemented by specific warning notices in the following chapters. This warning notices explains exactly how you must behave in order to protect yourself, others and objects from damage.

These operating instructions are a component of the device described here.

→ Please ensure the operating instructions are available at all times.

→ Please pass on the operating instructions to the subsequent owner.

The device may only be used under the following circumstances:

- The device is in full working order.
  - The device is used according to its intended purpose.
  - All operators of the device possess the necessary safety and risk awareness.
  - The instructions stipulated in this instruction manual are followed.
- Errors must be eradicated immediately; especially those which jeopardize safety.

## Intended use

The device is suitable for the following use:

- Distillation
- Purification of media such as chemicals and liquids
- Processing reaction batches
- Solvents recycling

A suitable operating location for the device is one of the following areas:

Chemical, pharmaceutical and biological laboratories in industry and universities.

Please observe the operating instructions in order to use the device for its intended purpose.



## Unauthorized use

Any use which deviates from the device's intended use is considered to be improper. The manufacturer does not accept liability for any damages resulting from non-permitted uses. The risk is carried by the operator alone.

→ It is not permitted for excess pressure to be applied to the device.

## Use in potentially explosive areas

→ Do not use the device in potentially explosive areas. The device is not protected against explosion. There is no explosion or ATEX protection available.

## Requirements to operate this unit

This product may only be operated and maintained by qualified personnel who are of legal age and have been instructed carefully. Others may only work with the unit under continuous supervision of an experienced person. Repairs may only be performed by qualified electricians.

## Operating company's obligations

- Only operate the device in full and proper working order.
- Ensure that only qualified personnel operate the device.
- Ensure that the personnel have received safety instructions in order to guarantee responsible and safe work procedures in the laboratory.
- Ensure that the device is positioned in a suitable location.
- Ensure that the device is sufficiently stable.
- Ensure that installation and operation of the device is only carried out in facilities which are fitted with the appropriate laboratory equipment (e.g. with air extraction units).
- Ensure that all screw connections are securely tightened.

### Depending on the medium used:

- Ensure that the rotary evaporator is operated only in conjunction with an extractor hood (at least 10-fold air change, with error monitoring), see DIN EN 14175 and DIN 12924.



## Operating personnel's obligations

- Verify that the distillation material can be evaporated safely and that the distillation residue is not explosive.
- Ensure that work which uses naked flames is not carried out in the vicinity of the device (risk of explosion).
- Ensure that the flow rate when removing liquids with flammable materials remains at < 1 m/s (electrostatic charge; risk of ignition).
- Ensure that gases classified in explosion group IIC are not produced by materials or during chemical reactions, e.g. hydrogen.
- Ensure that no devices are operated or assembled which are emission or radiation sources (electromagnetic waves) for the frequency range (3×10<sup>11</sup> Hz to 3×10<sup>15</sup> Hz).
- Ensure that no devices are operated or assembled which constitute emission or radiation sources for ionizing radiation or in the ultrasonic range.
- Ensure that no adiabatic compression or shock waves occur (shock wave combustion).
- Ensure that the use of materials which pose a potential risk of uncontrolled energy release is prohibited by an associated pressure increase (exothermic reaction; spontaneous combustion of dusts).
- Ensure that glass surfaces are only wiped with damp cloths.
- Ensure that ground joint connections are clean and sit securely attached.
- Please wear the appropriate protective clothing when working on the machine (protective glasses and if necessary, safety gloves).
- Ensure that sufficient heat transfer media are used.
- Ensure that the maximum excess pressure of the coolant equals no more than 1 bar in the condenser.
- Ensure that all tube connections are properly connected to ensure safe operation.
- Ensure that all cables and tubes are correctly laid and are located outside the operating and danger zone.
- Please avoid putting pressure on the display.



## Personnel qualification

The target group for this device is qualified personnel. The device may only be operated by individuals who have been instructed in its proper use by qualified personnel.

### Operating instructions



These operating instructions as well as the operating instructions for the Hei-VAP or Hei-VAP Industrial must be followed, read and understood by all persons working with the device (acknowledgment of the safety instructions is particularly important).

## Changes to the unit

No unauthorized changes may be made to the unit. No parts may be used which have not been approved by the manufacturer. Unauthorized changes result in the CE declaration of conformity losing its validity, and the appliance may no longer be operated.

The manufacturer is not liable for any damage, danger or injuries that result from unauthorized changes or from operating the unit other than described in this manual.



## Safety devices on the unit

Note	Description
	Name plate (for example: Hei-VAP Distimatic)
	Warranty seal
<p><b>Warning</b> Before opening the box disconnect power plug.</p> <p><b>Warnung</b> Vor dem Öffnen des Gehäuses Netzstecker ziehen.</p>	Note to disconnect the power connection prior to opening the device housing.
	Label on connection for multiple switched socket (Hei-VAP) or multiple socket (Hei-VAP Industrial) and vacuum pump. Indicates the maximum total connected load
	Ground symbol

## Residual dangers

Despite all precautions taken, residual risks can emerge which may not be immediately obvious! Adhering to the safety instructions, the intended use and the operating instructions as a whole can reduce residual risks!

### CAUTION Unintentionally rotating drive!



Injuries to hands.  
→ Ensure that the drive unit is switched off.



### WARNING Risk of slipping!



Risk of injury.  
After operation or in the event of malfunctions, there may be liquid on the floor close to the machine.  
→ Watch out for any wet spots and clean the floor if necessary.

### WARNING Errors!



Risk of injury.  
Malfunctions or operating states that may jeopardize the safety of operating personnel require the device to be brought to a standstill by disconnecting the power supply.  
→ Proper restoration of the machine's intended state is necessary.

### WARNING Hazardous materials and solvents!



There are risks posed by the leakage of hazardous substances and solvents from locations that are not properly sealed.  
→ Check whether all screw caps have been tightened properly at the threads to seal them off.  
→ Route all PTFE tubes into the vessels intended for them and fasten them securely to the vessel.  
→ Do not expose operating personnel to harmful vapors or gases. Extract waste air using a vapor outlet.  
→ Ensure that the separator for the power supply is easily accessible at all times.

### WARNING Hot surfaces!



Risk of scalding and burns.  
→ Allow the glass equipment to cool down.  
→ Allow media to cool down.





**DANGER** Danger to life due to dangerous electrical voltage!



Risk of serious injury.

Electrical residual energy remains in lines, equipment and devices after shutting down the device.

- Disconnect the power plugs from the energy source in order to establish zero potential.
- Only allow qualified electricians to perform work on the electrical supply system.
- Check electrical wiring on the device at regular intervals and replace when damaged.
- Only set up or disconnect connections when disconnected from the power supply.

**DANGER** Risk of injury or danger to life due to failure to observe the safety instructions and safety clearance!



Risk of injury.

Risks arise due to failure to observe the safety instructions and the safety clearance for the device.

- Follow all safety instructions and signs provided on the device and in these operating instructions. Maintain the appropriate safety clearance distance from the device.

**WARNING** Unauthorized access is prohibited!



Risk of injury.

Risks arise if unauthorized persons enter the danger zone of the device.

- The operator is responsible for ensuring that unauthorized persons (e.g. visitors) do not have access to the danger zones (service area, protected areas).



**DANGER** Failure to observe the danger zone, work area and service area!



Dangers are posed by electrical and mechanical energies, as well as by residual dangers.



- Please ensure a safe distance of 1m around the evaporator components.
- Do not place or store any objects in the work or service area.
- Deposit accessories, chemicals or tools in such a way that no dangers arise for the personnel.

**WARNING** Imploding glass devices!



Serious injuries caused by shattering glass.



- Check glass devices for damage (breakage, cracks etc.).

- Only use glass equipment in perfect condition.



**WARNING** Glass breakage!



Serious injuries due to shattering glass and glass breakage.



- Check glass devices for damage (breakage, cracks etc.).

- Only use glass equipment in perfect condition.

- Monitor pressure conditions in the glass attachment.

- Work carefully.

**DANGER** Risk of fire and explosion!



Serious risk of fire and explosion.

There is a risk of fire and explosions in the vicinity of the device. Smoking, naked flames and fire are strictly forbidden in the vicinity of the device.



- Do not store any flammable liquids in the danger zone of the device. A fire extinguisher must be kept in the vicinity of the device.
- Avoid potential sources of ignition such as flammable atmospheres, reactions or electrostatic charges.
- Avoid exothermic reactions or the spontaneous combustion of dust.
- Avoid adiabatic compression and shock waves.
- Take special care with reactions of explosion group IIC for which hydrogen can be released.



**DANGER** Danger when extinguishing fires!

Risk of serious injury as a result of chemical reactions.



Danger of chemical absorption.



Vigorous reactions with the medium can occur if water is used to extinguish the fire.



- Do NOT use water to put out the fire.
- Use extinguishing agents which do not react with the medium.
- Please observe the fire protection regulations and the fire extinguishing instructions they provide.

➤ **Device description**

The device is an automatic module, which is operated in combination with a rotary evaporator. It has the following functions:

- Automatic distillation (permanent operation)
- Automatic refill into the evaporator
- Automatic discharge of condensate from the evaporator
- Automatic drainage of residue (only on Distimatic including automatic drainage of residue)
- Automatic or manual termination of distillation

All the functions are available to you in automatic mode.



**Operation of Hei-VAP and Hei-VAP Industrial**

→ See Hei-VAP or Hei-VAP Industrial operating instructions.



➤ **Scope of delivery**

Hei-VAP Distimatic

Components	Quantity	Order number
Control box	1	11-300-004-89
Power cord	1	14-007-003-81 OR 14-007-005-45 OR 14-007-045-40 OR 14-007-009-36 (depending on your country)
Multiple switched socket	1	14-300-010-52
Wall bracket	1	11-300-006-62
Operating panel	1	11-300-004-91
Check valve for PTFE tube Ø 6 mm	1	11-300-006-66
Valve matrix	1	11-300-004-92
Multiple screw connection with flask sensor	1	11-300-004-96
Screw cap	1	23-30-01-07-38
Cut-out sensor	1	11-300-004-98
Rubber ring Ø 120 mm for cut-out sensor	1	23-30-01-06-35
PTFE tube Ø 6 mm (length 10 m)	1	23-30-01-04-28
Filter	1	11-300-003-78
Hose connector T-type	1	23-30-01-05-74
Overflow sensor for condensate vessel	1	14-300-011-41

Additional on Distimatic **including** automatic drainage of residue:

Components	Quantity	Order number
Check valve for PTFE tube Ø 8 mm	1	11-300-006-67
Condenser G9	1	514-00900-00
Residue pump	1	14-300-010-40
3/2 way valve	1	11-300-004-97
PTFE tube Ø 8 mm (length 4 m)	1	23-30-01-03-15
Overflow sensor for condensate and residue vessel	1	14-300-011-42



Hei-VAP Industrial Distimatic

Components	Quantity	Order number
Control box	1	11-300-004-89
Power cord	1	14-007-003-81 OR 14-007-005-45 OR 14-007-045-40 OR 14-007-009-36 (depending on your country)
Powerbox for Hei-VAP Industrial and powerbox for chiller (variant 3 x 400 V – 230 V, standard) OR Powerbox for Hei-VAP Industrial and powerbox for chiller (variant 1 x 230 V – 230 V)	2	11-300-007-01 OR 11-300-007-02
Multiple socket	1	14-300-010-50
Wall bracket	1	11-300-006-62
Operating panel	1	11-300-004-91
Check valve for PTFE tube Ø 6 mm	1	11-300-006-66
Valve matrix	1	11-300-004-93
Collector attachment	1	11-300-006-98
Control box attachment	1	11-300-007-07
Multiple screw connection with flask sensor	1	11-300-004-96
Screw cap	1	23-30-01-07-38
Cut-out sensor	1	11-300-004-98
Rubber ring Ø 80 mm for cut-out sensor	1	23-30-01-06-35
PTFE tube Ø 6 mm (length 10 m)	1	23-30-01-04-28
Filter	1	11-300-003-78
Hose connector T-type	1	23-30-01-05-74
Overflow sensor for condensate vessel	1	14-300-011-41

Additional on Distimatic **including** automatic drainage of residue:

Components	Quantity	Order number
Check valve for PTFE tube Ø 8 mm	1	11-300-006-67
Distributor from glassware set A OR Distributor from glassware set R	1	15-300-002-77 OR 15-300-002-76
Residue pump	1	14-300-010-40
3/2 way valve	1	11-300-004-97
PTFE tube Ø 8 mm (length 4 m)	1	23-30-01-03-15
Overflow sensor for condensate and residue vessel	1	14-300-011-42



## Storage and transport

**CAUTION****Damages as a result of improper transport!**

Damage can be caused to the device and the device mechanics in the case of improper transport.

→ Avoid jolting and impacts.

**WARNING****Hot surfaces!**

Risk of scalding and burns.

→ Allow the glass equipment to cool down.

→ Allow media to cool down.

**WARNING****Hazardous materials and solvents!**

Dangers exist due to the emergence of hazardous substances and solvents from inadequately sealed areas and the escaping of hazardous substances into the atmosphere.

→ Ensure that no hazardous substances and solvents adhere to the device components.

- Store and transport the device in the original packaging.
- Seal the packaging with adhesive tape.
- Store the device in a dry location.
- To carry the device, lift it from below.

## Unpacking the device

**CAUTION****Damages as a result of improper transport!**

Damage can be caused to the device and the device mechanics in the case of improper transport.

→ Avoid jolting and impacts.

- Unpack the device and if necessary, remove any protective films.
- Check scope of supply.

Has the device been damaged or is delivery incomplete?

→ Contact Heidolph Instruments.



## Overview of the components

### Hei-VAP Distimatic




### Hei-VAP Industrial Distimatic





## Explanation of the components



### Overall view

- 1 Control box

### Reverse side (connections)

- 2 Device mains plug
- 3 Mains socket for multiple switched socket (Hei-VAP) or multiple socket (Hei-VAP Industrial)
- 4 Mains socket for vacuum pump
- 5 Not assigned
- 6 Overflow sensor for condensate and/or residue vessel
- 7 3/2-way valve (only for Distimatic including automatic drainage of residue)
- 8 Residue pump (only for Distimatic including automatic drainage of residue)
- 9 Valve matrix
- 10 Cut-out sensor
- 11 Flask sensor
- 12 Operating panel

### Right side

- 13 Refill sensor
- 14 Refill valve

### Top



- 15 Mains switch
- 16 Cut-out switch
- 17 Flask sensor button, status indicator of the flask sensor and calibration button (green = ready for operation, red = medium detected)

### Front


- 18 Condensate pump
- 19 Check valve for PTFE tube Ø 6 mm




- 20 Operating panel
- 21 Display
- 22 Arrow keys **right/left**
- 23 Arrow keys **up/down**
- 24 **apply** key
- 25 **set** key
- 26 **parameter** key
- 27 **drain residue** key
- 28 **refill/drain** key
- 29 **start/stop** key




- 30 Wall bracket for installation of the control box
- 31 Wall bracket with control box




## Installation



- 43** Overflow sensor
- 44** Residue vessel  
(not included in scope of delivery)
- 45** Condensate vessel  
(not included in scope of delivery)
- 46** Product storage vessel  
(not included in scope of delivery)
- 47** Filter on PTFE tube  $\varnothing$  6 mm




## Installation



- 48** Residue pump  
(only for Distimatic including automatic drainage of residue)
- 49** Flow direction indicator
- 50** Check valve for PTFE tube  $\varnothing$  8 mm  
(only on Distimatic including automatic drainage of residue)
- 51** PTFE tube




Hei-VAP Distimatic



<b>52</b>	Multiple screw connection
<b>53</b>	Condenser G9 (only on Distimatic including automatic drainage of residue)
<b>54</b>	Condenser from glassware set G3 (only on Distimatic without automatic drainage of residue)
<b>55</b>	Cut-out sensor
<b>56</b>	Hose connector T-type
<b>57</b>	3/2 way valve (only on Distimatic including automatic drainage of residue)


<b>58</b>	Flask sensor
<b>59</b>	Screw cap GL32 (for use of condenser G9 without Distimatic)
<b>60</b>	Valve matrix
<b>61</b>	Evacuation valve
<b>62</b>	Condensate valve
<b>63</b>	Ventilation valve
<b>64</b>	Level sensor on collector
<b>65</b>	Collector




<b>66</b>	Multiple switched socket with connections for Hei-VAP, chiller and residue pump (total output = 3500 W)
<b>67</b>	Switch unit



Hei-VAP Industrial Distimatic



<b>68</b>	Distributor from glassware set A (only on Distimatic including automatic drainage of residue)	<b>76</b>	3/2 way valve (only on Distimatic including automatic drainage of residue)
<b>69</b>	Multiple screw connection	<b>77</b>	Multiple screw connection with flask sensor
<b>70</b>	Distributor from glassware set A (only on Distimatic without automatic drainage of residue)	<b>78</b>	Screw cap GL32 (for use of condenser G9 without Distimatic)
<b>71</b>	Cut-out sensor	<b>79</b>	Valve matrix
<b>72</b>	Distributor from glassware set R (only on Distimatic including automatic drainage of residue)	<b>80</b>	Evacuation valve
<b>73</b>	Distributor from glassware set R (only on Distimatic without automatic drainage of residue)	<b>81</b>	Condensate valve
<b>74</b>	Y-connector from glassware set A/R	<b>82</b>	Ventilation valve
<b>75</b>	Hose connector T-type	<b>83</b>	Level sensor on collector
		<b>84</b>	Collector




<b>85</b>	Powerbox for Hei-VAP Industrial
<b>86</b>	Connection for power cord
<b>87</b>	Device mains plug; connection for multiple socket
<b>88</b>	Connection for Hei-VAP Industrial
<b>89</b>	Powerbox for chiller
<b>90</b>	Connection for power cord
<b>91</b>	Device mains plug; connection for multiple socket
<b>92</b>	Connection for chiller
<b>93</b>	Multiple socket with connections for powerboxes and residue pump (total connected load = 3500 W)



## Function and connection principle

### Function principle of Distimatic

(example based on Hei-VAP Distimatic including automatic drainage of residue)




- ▶ PTFE tube
- ..... Vacuum tube
- Flask sensor control cable



## Connection principle of the vacuum circuit

### Variant 1:

Hei-VAP Precision including Woulff bottle




- |   |  |   |   |
|---|--|---|---|
| 1 | Hose connector T-type  | 4 | Vacuum valve (not applicable when using Rotavac Vario Control, Rotavac Vario Tec)                       |
| 2 | 3/2 way valve (only on Distimatic including automatic drainage of residue) | 5 | Vacuum box  |
| 3 | Woulff bottle  | 6 | Vacuum pump<br>Rotavac Valve Control<br>Rotavac Valve Tec<br>Rotavac Vario Control<br>Rotavac Vario Tec |

- ..... Vacuum tube
- Control cable



**Variant 2:**  
Hei-VAP Precision **without** Woulff bottle




7 Hose connector Y-type


..... Vacuum tube  
 ————— Control cable



**Variant 1:**  
Hei-VAP Value/Value Digital/Advantage **including** Woulff bottle



**Variant 2:**  
Hei-VAP Value/Value Digital/Advantage **without** Woulff bottle



1 Hose connector Y-type  
 2 3/2 way valve (only on Distimatic including automatic drainage of residue)


3 Vacuum pump Rotavac Vario Pumping Unit  
 4 Woulff bottle

..... Vacuum tube



## Connection principle of power supply

(Hei-VAP Distimatic)



1	Control box	4	Residue pump
2	Vacuum pump	5	Chiller
3	Multiple switched socket	6	Hei-VAP


— Electrical cable



## Connection principle of the vacuum circuit

(Hei-VAP Industrial Distimatic)

Front




1 Vacuum fitting

..... Vacuum tube



### Connection principle of the vacuum circuit

Reverse side




**1** Vacuum fitting

..... Vacuum tube



### Connection principle of power supply



<b>1</b>	Control box	<b>5</b>	Powerbox for Hei-VAP Industrial
<b>2</b>	Vacuum pump	<b>6</b>	Powerbox for chiller
<b>3</b>	Multiple socket	<b>7</b>	Chiller
<b>4</b>	Residue pump	<b>8</b>	Hei-VAP Industrial

→ Open wire ends, to be connected only by qualified personnel  
 ———— Electrical cable



## Installation

### WARNING



Unpacking and installation of the Automatic Module Distimatic should be limited to and permitted only by Heidolph staff or authorized Heidolph distributors only.



### Installation/disassembly of Hei-VAP and Hei-VAP Industrial

→ See also the operating instructions of Hei-VAP or Hei-VAP Industrial.



### Function principle of Distimatic

→ See chapter entitled „Function and connection principle“ - „Distimatic in general“ - „Function principle of Distimatic“.

The installation is described using the example of the Hei-VAP Distimatic including automatic drainage of residue (glassware set G3 with condenser G9) and Hei-VAP Industrial Distimatic including automatic drainage of residue (glassware set R).

Please refer to the chapter on „Explanation of the components“ for the differences in the glassware sets, multiple screw connection and the attaching of the cut-out sensor. You can also find a list of the glassware sets below as far as their compatibility with the respective order variant is concerned.



## Hei-VAP glassware sets compatibility

Order variant	Glassware set
Distimatic including automatic drainage of residue	Condenser G9
	G1
	G3
Distimatic without automatic drainage of residue	G4
	G6

## Hei-VAP Industrial glassware sets compatibility

Order variant	Glassware set
Distimatic including automatic drainage of residue	A, A2
	R
	Shorty R
Distimatic without automatic drainage of residue	A, A2
	R
	Shorty R

## Distimatic in general

### WARNING Hazardous materials and solvents!



There are risks posed by the leakage of hazardous substances and solvents from locations that are not properly sealed.

- Check whether all screw caps have been tightened properly at the threads to seal them off.
- Check the device components for hazardous substances and solvents.
- Ensure that the separator for the power supply is easily accessible at all times.
- Cut off PTFE tubes, which are routed through an overflow sensor and the multiple screw connection, with a cutting knife only at an angle of approx. 45°.
- When securing PTFE tubes to a connection, only cut them vertically with the HOLEX hose cutter.



If you use other cutters, there is a danger that the affected tube circuit could leak as a result of crushing the tube.



## Control box

- Place the control box on a flat, firm and dry surface with sufficient space. Also see the following sub-section „Wall bracket (optional)“.



## Wall bracket (optional)


You can clip the wall bracket to the wall or bolt it into the wall.

### Clipped:

- Clip the wall bracket to a stand bar secured horizontally to the wall by means of a hanging device (1) and slide it onto a vertical stand bar by means of fixing device (2).
- Route the PTFE tube coming from the product storage vessel through the brackets (3) and the cables into brackets (4).

### Bolted:

- Insert the hexagonal bolts  $\varnothing$  6 mm through the larger borehole on hanging device (1) at the front into the back borehole and tighten until hand-tight using a socket wrench SW 10 mm.
- Route the PTFE tube coming from the product storage vessel through the brackets (3) and the cables into brackets (4).



- Position control box on the suspended wall bracket.




## Refill valve and refill sensor

- Unscrew screw caps (5) and (6).




## Installation

→ Connect PTFE tube Ø 6 mm to connection (7) and tighten until hand-tight.




→ Connect the PTFE tube Ø 6 mm to connection (8) on filter and tighten until hand-tight and run into the product storage vessel.




## Installation

→ Route the PTFE tube Ø 6 mm into product storage vessel.




→ Connect PTFE tube Ø 6 mm to connection (9) and tighten until hand-tight.




## Condensate pump

- Remove the screw caps (10) from connections (11) and (12).




- Connect PTFE tubes Ø 6 mm to connections (13) and (14) and tighten until hand-tight.
- To integrate the check valve, vertically cut through the PTFE tube with the HOLEX hose cutter at about point (15) shown in the circle.



## Check valve in the condensate circuit


- Connect PTFE tubes Ø 6 mm to connections (16) and (17) and tighten until hand-tight.

**Important: Observe flow direction!**




## Overflow sensor for condensate vessel

- Cut off the end (18) of the PTFE tube Ø 6 mm with a cutting knife only at an angle of approx. 45° and route through the connections (20) and (19) of the overflow sensor.



- Suspend overflow sensor safely on the edge (21) of the condensate vessel.
- The immersion depth of the PTFE tubes in the vessel may be determined by pulling or pushing the PTFE tube (22).
- Ensure that the sheathed sensor wire is not detached from the insulation during installation of the PTFE tube.







## Residue pump

(only on Distimatic including automatic drainage of residue)

- Connect PTFE tubes Ø 8 mm to connections (23) and (26) and tighten until hand-tight.
- Set the rotary knob (24) to the maximum flow rate (100% = MAX).
- To integrate the check valve, vertically cut through the PTFE tube with the HOLEX hose cutter at about point (25) shown in the circle.



- Connect power cord into connection (27) and control cable into connection (28) and tighten until hand-tight.




## Check valve in the residue circuit

(only on Distimatic including automatic drainage of residue)


- Connect PTFE tubes Ø 8 mm to connections (29) and (30) and tighten until hand-tight.

**Important: Observe flow direction!**




## Overflow sensor on residue vessel

- Cut off the end (31) of the PTFE tube Ø 6 mm with a cutting knife only at an angle of approx. 45° and route through the connections (33) and (32) of the overflow sensor.



- Attach overflow sensor safely on the edge (34) of the residue vessel.
- The immersion depth of the PTFE tubes in the vessel may be determined by pulling or pushing the PTFE tube (35).






## Operating panel

→ Connect the cabling for operating panel to connection (36).

**Important: The connector must click into place completely.**



## Hei-VAP Distimatic

### WARNING Glass breakage!



Serious injuries due to shattering glass and glass breakage.



→ Check glass equipment for damage (breakage, cracks etc.).

→ Only use glass equipment in perfect condition.

→ Monitor pressure conditions in the glass attachment.

→ Work carefully.



### WARNING Hazardous materials and solvents!



There are risks posed by the leakage of hazardous substances and solvents from locations that are not properly sealed.

→ Check whether all screw caps have been tightened properly at the threads to seal them off.

→ Check the device components for hazardous substances and solvents.

→ Ensure that the separator for the power supply is easily accessible at all times.

→ Cut off PTFE tubes, which are routed through an overflow sensor and the multiple screw connection, with a cutting knife only at an angle of approx. 45°.

→ When securing PTFE tubes to a connection, only cut them vertically with the HOLEX hose cutter.




If you use other cutters, there is a danger that the affected tube circuit could leak as a result of crushing the tube.



## Condenser

(only on Distimatic including automatic drainage of residue)

- Remove condenser attachment on the condenser.




- Remove the condenser.
- Mount condenser G9 and secure it in place with the condenser attachment.





## Cut-out sensor

- Fix the cut-out sensor with rubber ring Ø 120 mm to the condenser.




## Valve matrix

- Fix the valve matrix to the condenser with the joint clamp.
- Ensure that the interconnection point is evenly bolted together and does not leak.




## Installation

- Connect PTFE tube Ø 6 mm to connection (1) and tighten until hand-tight.




## Multiple screw connection

- Route PTFE tube Ø 8 mm through connection (2) (only on Distimatic including automatic drainage of residue) and PTFE tube Ø 6 mm through connection (3) and secure in place so it is hand-tight.



## Installation

- Route PTFE tubes and flask sensor into the evaporating flask and secure the multiple screw connection at connection (4) until hand-tight.



### Optimization of the distillation process




- Refill evaporating flask only up to one third. Position the flask sensor accordingly.
- Use large evaporating flasks (3-5 liter variants) whenever possible.
- Use the following recommended immersion depths:

The end of the PTFE tube (5) Ø 6 mm varies. Flask sensor (6) ends just above the required maximum fill level. PTFE tube (7) Ø 8 mm (only on Distimatic including automatic drainage of residue) ends approximately 2 – 3 mm above the bottom of the evaporating flask.

This way your distillation process will become much faster.


- The immersion depth of the PTFE tubes and the flask sensor in the evaporating flask may be determined by loosening the respective screw cap slightly at the multiple screw connection and by pulling or pushing the PTFE tube or the flask sensor.
- Re-secure the screw caps on the multiple screw connection so they are hand-tight again afterwards.





## Screw cap GL32 (optional)

- If you wish to use the Hei-VAP with condenser G9 without the Distimatic, then secure the screw cap instead of the multiple screw connection to connection (8) and tighten until hand-tight.
- Remove the evaporating flask from connection (9), fill medium into the evaporating flask and then secure the evaporating flask into place again.



## Hose connector


### T-type, 3/2 way valve and vacuum tube connections




#### Connection principle of the vacuum circuit

- See chapter entitled „Function and connection principle“ - Hei-VAP Distimatic“-„Connection principle of the vacuum circuit“.

- Connect vacuum tubes to connections (10), (11) and (12).




- Connect vacuum tube to connection (13).




## Installation

→ Mount 3/2 way valve on stand rod (14) and secure using screws (15).




→ Connect vacuum tube to connections (16) and (17).



Vacuum circuit  
in direction of vacuum pump

## Installation

→ Connect vacuum tube to connection (18).



## Multiple switched socket and control box

### DANGER

### Danger to life due to dangerous electrical voltage!

Risk of serious injury.



Electrical residual energy remains in lines, equipment and devices after shutting down the device.

- Point out the power sockets to the operating personnel. Disconnect the power plugs from the energy source in order to establish zero potential.
- Only allow qualified electricians to perform work on the electrical supply system.
- Disconnect the device from the mains supply. Regularly check the electrical equipment (mains cables) of the device.
- Replace damaged power cords. Regularly check all power cords for damages during repair and maintenance work.
- Only set up or disconnect connections when disconnected from the power supply.

### Connection principle




→ See chapter entitled „Function and connection principle“ - Hei-VAP Distimatic“- „Connection principle of power supply“.




**Multiple switched socket:**

- Connect Hei-VAP, chiller and residue pump (only on Distimatic including automatic drainage of residue) to the connections (20) of the multiple switched socket (total output = 3500 W).
- Connect power cord (22) to the mains socket.
- Connect the control cable (19) of the switch unit to connection (21) on the multiple switched socket.



**Control box:**

- Connect connector (23) belonging to the switch unit to connection (24).
- Connect the vacuum pump to connection (25).
- Connect all the control cables according to their assignments to connections (26) (see chapter entitled „Explanation of the components“ - „Distimatic in general“).
- Connect control box power cord to connection (27).
- Connect the control box to the mains socket.



➤ **Hei-VAP Industrial Distimatic**

**WARNING Glass breakage!**



Serious injuries due to shattering glass and glass breakage.



→ Check glass devices for damage (breakage, cracks etc.).



→ Only use glass equipment in perfect condition.

→ Monitor pressure conditions in the glass attachment.

→ Work carefully.

**WARNING Hazardous materials and solvents!**



There are risks posed by the leakage of hazardous substances and solvents from locations that are not properly sealed.

→ Check whether all screw caps have been tightened properly at the threads to seal them off.

→ Check the device components for hazardous substances and solvents.

→ Ensure that the separator for the power supply is easily accessible at all times.

→ Cut off PTFE tubes, which are routed through an overflow sensor and the multiple screw connection, with a cutting knife only at an angle of approx. 45°. When securing PTFE tubes to a connection, only cut them vertically with the HOLEX hose cutter.



If you use other cutters, there is a danger that the affected tube circuit could leak as a result of crushing the tube.




## Condenser



→ Remove the clamping unit (1) at the condenser.

- Loosen thumb screws (2) on reverse side of protective cabinet and slide consoles (3) upwards with the condenser.
- Secure thumb screws (2) so they are hand-tight in this position.



## Cover




→ Detach cover (4).



## Distributor

(only on Distimatic including automatic drainage of residue)

→ Remove screw connection at distributor.



→ Remove the clamp at the distributor.



→ Remove the distributor.



### Valve body with valve

→ Remove the clamp (5) and the valve body (6) including the valve.



### Cassette

→ Remove the supporting frame from the cassette.




→ Unscrew the supporting frame.




### Multiple screw connection and distributor

→ Route PTFE tube Ø 8 mm through connection (7) (only on Distimatic including automatic drainage of residue) and PTFE tube Ø 6 mm through connection (8) and secure in place so it is hand-tight.




## Installation

- Connect the supplied distributor to connection (10) so it is hand-tight (only on Distimatic including automatic drainage of residue)
- Route PTFE tubes and flask sensor through distributor into the evaporating flask and secure multiple screw connection at connection (9) until hand-tight.




- Loosen thumb screw (11) on reverse side of protective cabinet and slide consoles (12) downwards with the condenser.
- Re-secure thumb screw (11) so it is hand-tight.



## Installation

- Fix the distributor to connection (13) with clamping unit (14).






**Optimization of the distillation process**

- Refill evaporating flask only up to one third. Position the flask sensor accordingly.
- Use large evaporating flasks whenever possible.
- Use the following recommended immersion depths:  
The end of the PTFE tube (15) Ø 6 mm varies. PTFE tube (16) Ø 8 mm (only on Distimatic including automatic drainage of residue) ends approximately 2 - 3 mm above the bottom of the evaporating flask. Flask sensor (17) ends just above the required maximum fill level.

This way your distillation process will become much faster.

- The immersion depth of the PTFE tubes and the flask sensor in the evaporating flask may be adjusted by loosening the respective screw cap slightly at the multiple screw connection and by pulling or pushing the PTFE tube or the flask sensor.
- Re-secure the screw caps on the multiple screw connection so they are hand-tight again.



**Cut-out sensor**

- Connect cut-out sensor with rubber ring Ø 80 mm to distributor (18) (for glassware set R) or condenser opening (19) (for glassware set A).



18



19



## Valve matrix

- Fix the valve matrix with the clamping unit to connection (20) on distributor.
- Ensure that the interconnection point is evenly bolted together and does not leak.



20



## 3/2 way valve,

hose connector T-type, and vacuum tube connections

### Connection principle of the vacuum circuit



- See chapter entitled „Function and connection principle“ - Hei-VAP Industrial Distimatic“- „Connection principle of the vacuum circuit“.




- Clamp 3/2 way valve onto metal cladding (22) using the clamping device and secure with adjusting screws (21).

21


22

- Connect vacuum tubes to connections (23), (24) and (25).




## Installation

→ Connect vacuum tube to connections (26) and (27).



→ Connect vacuum tube to connection (28).



## Installation

→ Connect the vacuum tube (29) to the evacuation valve of the valve matrix.



## Cover

→ Re-attach the cover (30).





## Powerbox, multiple socket and control box

### DANGER Danger to life due to dangerous electrical voltage!



Risk of serious injury.

Electrical residual energy remains in lines, equipment and devices after shutting down the device.

- Point out the power sockets to the operating personnel. Disconnect the power plugs from the energy source in order to establish zero potential.
- Only allow qualified electricians to perform work on the electrical supply system.
- Disconnect the device from the mains supply. Regularly check the electrical equipment (power cords) of the device.
- Replace damaged power cords. Examine all mains cables for damages at regular intervals as part of the repair and preventive maintenance work.
- Only set up or disconnect connections when disconnected from the power supply.

### Connection principle




- See chapter entitled „Function and connection principle“ - Hei-VAP Industrial Distimatic“- „Connection principle of power supply“.

### Powerbox for Hei-VAP Industrial or powerbox for chiller:

- Ensure that a suitable series fuse is connected in the in-house system. There is no integrated fuse in the powerbox.
- Route the power cord for the Hei-VAP Industrial / chiller through the cable feed (32).


#### a. On variant 3 x 400 V – 230 V (standard):

- Connect PE cables (33), L1 (34), L2 (35), L3 (36), N (37) to connections (33) through (37).



#### b. On Variant 1 x 230 V – 230 V:


- Connect PE cables (33), L1 (34), N (39) to connections (33), (34) and (39).



- Fit a mains plug to suit the region on the mains supply cable (31) and connect to mains socket. You can also attach the power supply cable (31) directly to the building electrical installation.
- Secure powerbox power cord in connection (38).

### Multiple socket:

- Connect powerboxes and residue pump (only on Distimatic including automatic drainage of residue) to connections (45) in the multiple socket (total output = 3500 W).





**Control box:**

- Connect multiple socket to connection (42).
- Connect the vacuum pump to connection (43).
- Connect all the control cables according to their assignments to connections (44) (see chapter „Explanation of the components“ - „Distimatic in general“).
- Connect control box power cord to connection (41).
- Connect the control box to the mains socket.



41

42

43

44



➤ **Start-up**

**CAUTION** The mains voltage and specification of the mains voltage on the name plate do not coincide!



Damage to property as a result of overvoltage.

- Please ensure that the mains voltage coincides with the voltage specified on the name plate.

**DANGER** Danger of electric shock or short-circuit!



Electric shock or short circuit due to damaged insulation.

- Ensure that all power cords, tubes and connecting cables have been laid correctly in the area where heat is generated.

**CAUTION** Unintentional switch-on of the device!



Injury and burns to the hands.



- Switch off the device.
- Unplug the mains plug after use.

**Preparatory steps**



**Rotary evaporator, vacuum pump, chiller**

- See operating instructions for Hei-VAP or Hei-VAP Industrial, vacuum pump and chiller.

- Switch on the rotary evaporator, vacuum pump and chiller with the respective mains switch.

If you prefer to use tap water instead of a chiller, start the water flow up during the preparation process for automatic mode (see chapter entitled „Automatic mode“ - „Preparatory steps“).



## Switching the control box on



### Automatic mode is not activated

Automatic mode is not active after switching the device on.

→ Switch on the control box using the mains switch (1) (the cut-out switch must not be activated).

After a few seconds, the operating state **process stopped** appears in the display of the operating panel. The device is ready for operation.



## Operation

### WARNING Hot surfaces!



Risk of scalding and burns.

- Allow the glass devices to cool down sufficiently.
- Allow the media to cool down.



### WARNING Hazardous materials and solvents!



There are risks posed by the leakage of hazardous substances and solvents from locations that are not properly sealed.

- Check whether all screw caps have been tightened properly at the threads to seal them off.
- Guide all PTFE tubes into the vessels intended for them and fasten them securely to the vessel.
- Do not expose operating personnel to harmful vapors or gases. Extract waste air using a vapor outlet.
- Ensure that the separator for the power supply is easily accessible at all times.



## Operating panel

The device is operated via the operating panel. The operating elements are described below.

### Control elements

Control element	Description
Display	Displays the operating states, parameters and messages.
Arrow keys <b>up/down</b>	<ol style="list-style-type: none"> <li>Select individual parameters (within the menu).</li> <li>Change the characters/digits of a parameter setting (within a parameter).</li> </ol>
Arrow keys <b>right/left</b>	<ol style="list-style-type: none"> <li>Navigate to the next character/digit of a parameter setting (within a parameter).</li> <li>Navigate between parameter settings (within a parameter with several parameter settings).</li> </ol>
<b>set</b> key	Select the first parameter setting (within a parameter with several parameter settings).
<b>set</b> and <b>apply</b> keys (in combination)	<ol style="list-style-type: none"> <li>Select individual parameter settings (press „set“ for at least 2 seconds) and select with the cursor (<b>apply</b>) (within a parameter).</li> <li>Save changed parameter setting (press <b>apply</b> for at least 2 seconds and then <b>set</b> for at least 2 seconds; within a parameter).</li> </ol>
<b>parameter</b> key	<ol style="list-style-type: none"> <li>Open menu.</li> <li>Leave menu.</li> </ol>
<b>drain residue</b> key	Residues, if any, in the evaporating flask, are removed manually. The residue pump drains the residue as long as you keep the key pressed (only on Distimatic including automatic drainage of residue and if automatic mode is not activated).
<b>refill/drain</b> key	Collector is manually emptied (if automatic mode is not activated). Automatic mode is enabled or disabled.
<b>start/stop</b> key	<p><b>start:</b> If an operating pump is connected, vacuum will be applied to the system.</p> <p><b>stop:</b> The system will be ventilated.</p>



## Operating states

Operating state	Description
<b>process stopped</b>	Automatic mode is disabled. Basic condition after activation of device or end of automatic mode.
<b>Status display</b>	Automatic mode is activated. Automatic mode in final process. If the refill sensor does not detect any medium during the refill, the final process is initiated. The remaining media is distilled.
<b>endprocess</b>	Following, the mains sockets for the rotary evaporator and the vacuum pump are deactivated at the control box. The vacuum circuit is ventilated. The condensate pump pumps out the condensate.

## Select operational mode

After switching on the unit you can choose between two different operational modes.

Select Sensor-Mode by pressing the set key and the arrow key <.  
Select Time-Mode by pressing the set key and the arrow key >.

Once you selected the Sensor-Mode a S will be visible on the display.  
Once you selected the Time-Mode a T will be visible on the display.

Changing modes is only possible after resetting the unit.



## Set parameters – Sensor-Mode

### Parameter overview

All parameters of the following table are settable. The settable criteria of a parameter (parameter settings) are marked in the following with the symbols „>...<“.

Parameter	Description
<b>Start/stop</b>	To gain access to the menu.
<b>Refill to start initial filling</b>	a. The key <b>refill</b> starts the pre-programmed operation. b. The key <b>parameter</b> allows for pre-setting all parameters.
<b>Time to refill &gt;...&lt;</b>	Time between refilling of the medium. If the preset time has expired, the flask sensor checks whether there is still any medium in the evaporating flask and triggers product refilling if needed.
<b>Extra time until drain off</b>	The residue in the evaporating flask is drained by the residue pump if the evaporation process has stagnated for the time period set in the parameter Extra time until drain off.
<b>Drain time cond &gt;...&lt; resi &gt;...&lt;</b>	Cond = Drainage of condensate Please enter the required time to drain condensate from the collector Resi = Drainage of residue Please enter the required time to drain residue from the evaporating flask.
<b>ENDPROCESS evaporate time &gt;...&lt;</b>	Pre-program the time frame for the unit to power off all periphery after the last cycle has been executed.
<b>ENDPROCESS draining cond &gt;...&lt; resi &gt;...&lt;</b>	Prior to powering off, the collector (condensate) and the evaporating flask (residue) can be drained. You have the option to allow for a final drainage (ON) or not (OFF).
<b>Residue pump during process &gt;...&lt;</b>	To drain the residue this option must be set ON.
<b>Refill to start initial filling</b>	Start the process by pressing the refill key.
<b>Overflow Collection Vessel &gt;...&lt;</b>	Activate the overflow power-off by pressing the ON key or not (OFF).
<b>Mo 09:00 2006-01-27</b>	Date and time display format. Here you can set the current date and time. Since error codes are always stamped with time, we recommend you to keep the date up to date in order to facilitate error analysis.

Drainage of condensate or residue can be performed manually by pressing the **refill / drain** key (condensate) and **drain residue** key (residue).



## Set parameters – Time-Mode

### Parameter overview

All parameters of the following table are settable. The settable criteria of a parameter (parameter settings) are marked in the following with the symbols „>...<“.

Definition of a **Step** – One step consists of an evaporating flask refill along with an evaporation time period.

Rule of thumb: the evaporating flask refills within approx. 20 ml / sec..

Definition of a **Cycle** – One cycle consists of numerous steps (to be set by operator). After every cycle residue will be drained off.



Parameter	Description
<b>Start/stop</b>	To gain access to the menu.
<b>Refill to start initial filling</b>	a. The key refill starts the pre-programmed operation. b. The key parameter allows for pre-setting all parameters.
<b>Step fill &gt;...&lt;</b>	Pre-program steps fill = enter time in minutes / seconds to refill evaporating flask.
<b>evap &gt;...&lt;</b>	evap = enter time in minutes / seconds to evaporate. In this time frame the flask is not refilled.
<b>steps &gt;...&lt;</b>	steps = enter number of steps to the final cycle.
<b>Process stop after &gt;...&lt; cycles</b>	Enter the number of cycles for the process. After the last cycle the system will power off.
<b>Adjust pressure for next cycle &gt;...&lt;</b>	To drain residue the system will release vacuum and vent. Enter the time in minutes / seconds your process requires to reach the pre-programmed vacuum level again. After this time frame the next cycle will start.
<b>Drain time cond &gt;...&lt;</b>	Cond = Drainage of condensate Please enter the required time to drain condensate from the collector.
<b>resi &gt;...&lt;</b>	Resi = Drainage of residue Please enter the required time to drain residue from the evaporating flask.
<b>ENDPROCESS evaporate time &gt;...&lt;</b>	Pre-program the time frame for the unit to power off all periphery after the last cycle has been executed.
<b>ENDPROCESS drain time cond &gt;...&lt;</b>	Prior to powering off, the collector (condensate) and the evaporating flask (residue) can be drained. You have the option to allow for a final drainage (ON) or not (OFF).
<b>Residue pump during process &gt;...&lt;</b>	To drain the residue this option must be set ON.
<b>Refill to start initial filling</b>	Start the process by pressing the refill key.
<b>Overflow Collection Vessel &gt;...&lt;</b>	Activate the overflow power-off by pressing the ON key or not (OFF).
<b>Mo 09:00</b> <b>2006-01-27</b>	Date and time display format. Here you can set the current date and time. Since error codes are always stamped with time, we recommend you to keep the date up to date in order to facilitate error analysis.

Drainage of condensate or residue can be performed manually by pressing the **refill / drain** key (condensate) and **drain residue** key (residue).



All parameters of the following table are not settable and cannot be operated.

Parameter	Description
<b>AI:</b> <b>1: 00000</b> <b>2: 01000</b> <b>3: 00253</b>	Switching state of the device inputs and outputs. Please refer to the 6 switching states in the following menu overview screen.
<b>ESC+C..</b>	Escape key



- To open the menu, press the **down** arrow key.
- To navigate within the menu, press the **right/left** arrow keys.
- To leave the menu, press the **up** arrow key.

## Changing the parameter settings

- Press the **parameter** key. The menu opens.
- Choose individual parameters with the **up/down** arrow keys.
- Press the **set** key (for at least 2 seconds). In the display, the flashing cursor underscores the first digit/character of the parameter setting.
- Press the **apply** key. In the display, the flashing cursor highlights the complete first digit/character in black color.
- Change the parameter settings using the **up/down** arrow keys.
- This applies to all parameter settings except for **On** or **Off**:  
Navigate to the next digit/character with the **left/right** arrow keys and adjust these as described in the previous step.
- In order to save the changed parameter settings, press the **apply** key (minimum of 2 seconds). In the display, the flashing cursor underscores the first digit/character of the parameter setting.
- Press the **set** key (minimum of 2 seconds) until the previously flashing cursor no longer underscores the first digit/character of the parameter setting.
- To exit the parameter menu, press the **parameter** key.



## Navigating between parameter settings

Some parameters have multiple options for settings, see, for example, the parameter **endprocess parameter ...** with the parameter settings **empty** and **delay**. Proceed as follows to choose individual parameter settings.

- Press the **set** key (for at least 2 seconds).
- Navigate between individual parameter settings with the **Left/Right** arrow keys.
- Press the **apply** key to highlight the first digit/character of the parameter setting selected with the cursor.

Please refer to the sub-section „Changing the parameter settings“.

## Setting date and time

### Date and time update



When the device is switched off, date and time will be automatically updated for up to 80 hours. As soon as this time period is exceeded, date and time must be set again.

An operating state or a message (except for error codes) is shown in the display.

- Press the **down** arrow key. Date and time appear in the display.
- Press the **set** key (for at least 2 seconds). The cursor > highlights the parameter **stop**.
- Press the **down** arrow key until the cursor highlights the parameter **set**.
- Press the **apply** key. The cursor highlights the parameter **clock**.
- Press the **apply** key. The cursor highlights the parameter **set clock**.
- Press the **apply** key. In the display the date and time display format appears. You can now change the setting.
- In order to change individual parameter settings, press the **up/down** arrow keys.
- In order to navigate between parameter settings and rows, press the **left/right** arrow keys.
- In order to save the new date and time parameter setting, press the **apply** key.
- To exit the parameter menu again, press the **set** key several times until date and time appear in the display.




## ➤ Adjusting the sensitivity of the sensors (optional)

You can adjust the sensitivity of the refill sensor, cut-out sensor and the level sensor.

- Turn screw (1) clockwise (sensor more sensitive ⇒ for non-polar media) or counterclockwise (sensor less sensitive ⇒ for polar media).
- You can also perform a rough adjustment of the cut-out sensor and the level sensor by decreasing or increasing the distance between the sensor and the glass surface. In the case of media with low polarity, the sensor should be positioned closer to the glass surface accordingly. In the case of media with high polarity, the sensor distance is not important.

### Refill sensor



1

### Cut-out sensor




1



## Level sensor on collector

You can modify the height of the level sensor.

- Loosen screw connection (2) and push the level sensor upwards or downwards (3). The higher the level sensor is positioned, the later the condensate will be pumped out of the collector.
- Turn screw (4) clockwise (sensor more sensitive ⇒ for non-polar media) or counterclockwise (sensor less sensitive ⇒ for polar media).



## Operating the cut-out switch

The cut-out switch is operated in critical cases of safety.

- Operate the **cut-out switch** (1) to interrupt the power supply immediately.
- Before putting the device back into operation, clarify the cause of the fault first (see chapter entitled „Error codes“).
- To put the device back into operation, turn the **cut-out switch** (1) to the right and switch the device on using the mains switch.
- Now follow the chapter entitled „Start-up“.



➤ Error codes



**Date and time**

Since error codes are automatically stamped with date and time, we recommend you to keep the date up to date in order to facilitate error analysis.

➔ Regularly check whether date and time are up to date (see chapter „Operation“ – „Set parameters“ – „Setting date and time“).

Error code	Cause	Consequence	Measure
<b>Error 1: Cut-out sensor</b>	a. Cut-out sensor not connected.	The cut-out sensor triggers safe shutdown and initiates the final process (in the event of an error). The error code appears.	a. Connect the cut-out sensor.
	b. Cut-out sensor not placed correctly.		b. Place the cut-out sensor as described in the chapter „Installation“.
	c. The cut-out sensor is responding too sensitively to small drops that are falling down within the condenser on the wall.		c. Set the cut-out sensor to be less sensitive (see chapter „Operation“ – „Adjusting the sensitivity of the sensors“).
	d. The condensate has accumulated in the condenser and can no longer be discharged. Valve at the valve matrix is clogged.		d. Clean the valves at the valve matrix.
	e. Cable break in the cut-out sensor.		e. Contact Technical Service.
	f. The condensate has accumulated in the condenser and can no longer be discharged. The valve matrix is defective.		f. Contact Technical Service.

Error code	Cause	Consequence	Measure
<b>Error 2: Unable to drain collector</b>	The condensate in the collector vessel can no longer be discharged.	The level sensor at the collector triggers safe shutdown and initiates the final process (in the event of an error). The error code appears.	a. Set the level sensor on the collector to be less sensitive (see chapter „Operation“ – „Adjusting the sensitivity of the sensors“).
	a. The level sensor at the collector is not responding to a dip in the fill level possibly since there are drops of condensate in the collector or the sensor adjustment is such that it is too sensitive.		b. Clean the PTFE tube.
	b. The PTFE tube at the collector is clogged.		c. Clean the condensate pump.
	c. The condensate pump is dirty.		d. Contact Technical Service.
	d. Cable break in the level sensor at the collector.		e. Contact Technical Service.
<b>Error 3: Collection vessel</b>	e. The condensate pump is defective.	The overflow sensor for condensate and residue vessel (only on Distimatic including automatic drainage of residue) triggers safe shutdown and initiates the final process (in the event of an error). The error code appears.	a. Connect the level sensor at the condensate or residue vessel.
	a. Overflow sensor for condensate and residue vessel is not connected (only on Distimatic including automatic drainage of residue).		b. Drain the condensate vessel or residue vessel.
	b. The condensate vessel or residue vessel is full.		c. Contact Technical Service.
	c. Cable break in the overflow sensor for condensate and residue vessel.		

## Error Codes

Error code	Cause	Consequence	Measure
<b>Error 4: Unable to drain residue</b>	Automatic drainage of residue active: The residue in the evaporating flask can no longer be drained.	The flask sensor triggers safe shutdown and initiates the final process (in the event of an error). The error code appears.	a. Compare suction and pressure height of the residue pump with the data of the maximum suction and pressure height given in chapter „Technical data“ and adjust the heights correspondingly.
	a. Suction and pressure height of the residue pump are exceeded.		b. Adjust the flow rate of the residue pump using the rotary knob to 100 %.
	b. Flow rate of the residue pump is set too low.		c. Clean the residue pump (see chapter entitled „Cleaning“ - „Circuit and flask sensor“ - „Residue circuit“).
	c. The residue pump is dirty.		d. Adjust the viscosity of the medium for the new evaporation process.
	d. The viscosity of the medium is too high.		e. Contact Technical Service.
	e. Cable break in the flask sensor.		f. Contact Technical Service.
	f. The residue pump is defective.		g. Correct the position of the PTFE tube Ø 8 mm for the automatic drainage of residue (see chapter „Installation“).
g. PTFE tube Ø 8 mm for the automatic drainage of residue (only on Distimatic including automatic drainage of residue) incorrectly positioned.			

## Maintenance, Cleaning, Service

## ➤ Maintenance



### Servicing the Hei-VAP and Hei-VAP Industrial

➔ See also the operating instructions of Hei-VAP or Hei-VAP Industrial.

The device is maintenance-free.

Is repair required?

➔ Contact Heidolph Instruments. Repair must be performed by a specialist authorized by Heidolph Instruments.

### DANGER



#### Risk posed by electrical voltage!

Risk of damage to health and to the device.



➔ Remove mains plug before opening the housing.

## ➤ Cleaning

### Housing

#### CAUTION



#### Damage to property as a result of corrosive cleaning agents!

Damages to the surface of the device.

➔ To clean the housing and device surface, use a damp cloth (mild soap solution). Do not use cotton waste, scouring agents, acids, alkaline solutions, chlorine bleach, chlorine-based cleaning products or products which contain metallic components.

### Circuits and flask sensor

#### WARNING



#### Glass breakage!

Serious injuries due to shattering glass and glass breakage.

➔ Check glass devices for damage (breakage, cracks etc.).

➔ Only use glass equipment in perfect condition.

➔ Monitor pressure conditions in the glass attachment.

➔ Work carefully.



**WARNING Hot surfaces!**

Risk of scalding and burns.

- Allow the glass equipment to cool down.
- Allow media to cool down.

**WARNING Hazardous materials and solvents!**

There are risks posed by the leakage of hazardous substances and solvents from locations that are not properly sealed.

- Check whether all screw caps have been tightened properly at the threads to seal them off.
- Route all PTFE tubes into the vessels intended for them and fasten them securely to the vessel.
- Do not expose operating personnel to harmful vapors or gases. Extract waste air using a vapor outlet.
- Ensure that the separator for the power supply is easily accessible at all times.

**Cleaning agents**

To ensure thorough cleaning, replace contaminated cleaning agents during the process for clean cleaning agents, if necessary.

- Ensure that the device is in the Sensor-Mode and in the operating state **process stopped**.
- Allow residue pump and condensate pump to continue running for an additional 10 seconds until the residue and condensate circuits are drained.

**Product storage circuit**

- Route the PTFE tube which leads to the product storage vessel into a vessel containing cleaning agents (e.g. solvent).
- Create a vacuum.
- Now follow the chapters entitled **Start-Up - Set parameters** to convey cleaning agent into the flask.
- Remove the PTFE tube from the vessel containing cleaning agents and direct into the atmosphere. Air will be conveyed into the evaporating flask.
- Wait 10 seconds until the product storage circuit is emptied.

**Condensate circuit**

- To create atmospheric pressure within the evaporator system, ventilate the rotary evaporator.
- Hei-VAP: Remove the vacuum attachment or vacuum tube (glassware set G1) from the uppermost condenser opening; Hei-VAP Industrial: Remove vacuum fitting.
- Then press the **start/stop** key. The message **please preset flask-level manually** appears in the display. Disregard this message.
- Use the uppermost condenser opening to fill in the cleaning agent. The cleaning agent will be discharged by the condensate pump.
- Wait 10 seconds until the cleaning agent has drained into the collector.
- To trigger the level sensor of the collector manually, position your index finger on the level sensor (between the collector and the metal piece onto which the level sensor is fastened). The orange level sensor LED will light up and the collector will be drained.
- Repeat this process until the collector is completely empty.
- Wait 10 seconds until the condensate circuit is emptied.

**Residue circuit**

- Pump cleaning agents, as outlined under „Product storage circuit“ into the evaporating flask.
- Route the PTFE tube which leads to the residue vessel into an empty vessel.
- Press the „**drain residue**“ key. Cleaning agent will be drained by the residue pump.
- Wait 10 seconds until the residue circuit is emptied.

**Flask sensor**

- Remove the flask sensor out of the evaporating flask and glassware set and clean with a cloth drenched with cleaning agent.

## ➤ Disassembly

**Disassembly of the Hei-VAP and Hei-VAP Industrial**

- See also the operating instructions of Hei-VAP or Hei-VAP Industrial.

**WARNING Hot surfaces!**

Risk of scalding and burns.

- Allow the glass equipment to cool down.
- Allow media to cool down.

**WARNING Glass breakage!**

Serious injuries due to shattering glass and glass breakage.



- Check glass devices for damage (breakage, cracks etc.).
- Only use glass equipment in perfect condition.
- Monitor pressure conditions in the glass attachment.
- Work carefully.

**WARNING Hazardous materials and solvents!**

There are risks posed by the leakage of hazardous substances and solvents from locations that are not properly sealed.



- Check the device components for hazardous substances and solvents.

- Switch off the device.
- Disconnect all plug connections.
- Remove all the device components in the reverse sequence to the installation (see chapter entitled „Installation“).

## ➤ Disposal

**WARNING Hazardous materials and solvents!**

There are risks posed by the leakage of hazardous substances and solvents from locations that are not properly sealed.

- Check the device components for hazardous substances and solvents.

- Ensure that the device is disposed of properly according to the valid national legal regulations.
- Dispose of the packaging material correctly in accordance with the valid, national legal regulations.



## ➤ Contact / Technical Service

If your device is not working properly:

- Please inform Heidolph Instruments by using our contact information.

You have contacted Heidolph Instruments?

- Copy and complete the Confirmation of condition of unit from these operating instructions.
- Please repack the device appropriately for transport and send to Heidolph Instruments together with the Confirmation of condition of unit.

## Our contact details

**UK United Kingdom**

Phone: 01799-5133-20

E-mail: [sandra.mcneill@radleys.co.uk](mailto:sandra.mcneill@radleys.co.uk)

[www.heidolph-instruments.co.uk](http://www.heidolph-instruments.co.uk)

**All other countries**

Heidolph Instruments GmbH & Co. KG

Technical Service

Walpersdorfer Str. 12

91126 Schwabach

Germany

Phone: +49-9122-9920-74

E-mail: [service@heidolph.de](mailto:service@heidolph.de)

[www.heidolph.de](http://www.heidolph.de)



## ➤ Technical data

### Distimatic in general

Permissible ambient conditions	5 - 31°C at 80 % relative humidity 32 - 40 °C linear decrease up to 50% relative humidity 0 - 2000 m a.s.l. Contamination level 2 Overvoltage category II
Evaporation rates (L/h) $\Delta T^*$ 40°C for Hei-VAP Distimatic (continuous operation)	Water 1.2 Ethanol 3.5 Acetone 4.4 Toluene 6.3
Airborne sound level	Significantly lower than 80 dB(A)

### Materials:

Collector	Borosilicate glass
Ground joint parts	PTFE
Laboratory screw joints	PPS/PTFE
Collector valve/seal	PTFE/FFKM
Evacuation valve/seal	PVDF/FKM
Ventilation valve/seal	PEEK/FFKM
Refill valve/seal	PTFE/FFKM
Tube screw connections	PVDF/FKM/PTFE
PTFE tubes	PTFE; $\varnothing$ 8x6 mm und $\varnothing$ 6x4 mm
Check valve/seal	PFA/FFKM
Filter	PTFE; POR 1/G 1, nominal width of pores 100 - 160 $\mu$ m
Sensor head	PTFE

\*  $\Delta T$  = Difference between heating bath temperature and boiling temperature



### Control box

Voltage	230 V
Frequency	50/60 Hz
Measurements without mounted components (W x D x H)	300 x 200 x 120 mm (approx.)
Weight	5 kg (approx.)
Protection class	IP54
Power input	50 VA
Connection	Multiple switched socket (Hei-VAP) or multiple socket (Hei-VAP Industrial)
	Vacuum pump
	Overflow sensor for condensate and residue vessel (only on Distimatic including automatic drainage of residue)
	3/2 way valve
	Residue pump (only on Distimatic including automatic drainage of residue)
	Valve matrix
	Cut-out sensor
	Flask sensor
	Operating panel

### Wall bracket

Dimensions (W x D x H)	390 x 245 x 170 mm (approx.)
Weight	1 kg (approx.)

**Multiple switched socket (only on Hei-VAP)**

Total power	3500 W
Measurements of multiple socket excluding switch unit (W x D x H)	520 mm x 84 mm x 50.5 mm (approx.)
Weight	1 kg (approx.)

**Powerbox (only on Hei-VAP Industrial)**

Dimensions (W x D x H)	150 x 150 x 125 mm (approx.)
Weight	3 kg (approx.)
Protection class	IP54
Power input	9.5 VA
Connection	Hei-VAP Industrial / chiller

**Multiple socket (only on Hei-VAP Industrial)**

Total power	3500 W
Dimensions (W x D x H)	262 mm x 59.3 mm x 43.9 mm
Weight	500 g (approx.)

**Operating panel**

Dimensions (W x D x H)	160 x 100 x 50 mm (approx.)
Weight	400 g (approx.)
Protection class	IP65
Display	Digital

**Residue pump (only on Distimatic including automatic drainage of residue)**

Dimensions (W x D x H)	110 x 161 x 191 mm (approx.)
Weight	1.5 kg (approx.)
Protection class	IP65
Power input	300 VA
Flow rate with atmospheric pressure	Approx. 2.6 liters/min (measured with water at 20 °C)
Maximum suction height	3 mWS
Maximum pressure height	10 mWS
Maximum permissible medium temperature	5 - 80 °C

**Residue pump (only on Distimatic including automatic drainage of residue)****Materials:**

Head parts	PVDF
Diaphragm	PTFE-coated
Valves	FFPM
Resonating diaphragm	PTFE

**Condensate pump**

Protection class	IP00
Power input	9 VA
Flow rate at atmospheric pressure	Approx. 0.6 liter/min (measured with water at 20 °C)
Maximum suction height	3 mWS
Maximum pressure height	10 mWS
Total power	3500 W
Maximum permissible medium temperature	5 - 80 °C
Materials:	
Head parts	PVDF
Diaphragm	PTFE-coated
Valves	FFPM
Resonating diaphragm	PTFE



## EC Declaration of Conformity



### EC Declaration of Conformity

→ See attachment „EC Declaration of Conformity“.

## Warranty bond



The Heidolph Instruments company provides a 3-year warranty for the products described here (excluding glass and wearing parts) if you register using the warranty card enclosed or online (www.heidolph.com). The warranty is valid from the point of registration. The serial number is also valid without registering. The warranty covers part and manufacturing defects.

In the case of a part or manufacturing defect, the device shall be repaired or replaced free of charge under the terms of the warranty.

Heidolph Instruments shall not assume liability for any damages incurred as a result of improper handling or transport.

Guarantee claim?

→ Please inform Heidolph Instruments should you wish to make a guarantee claim.



## Confirmation of condition of unit

→ In the case of repair, copy and complete the Confirmation of condition of unit and send it to Heidolph Instruments (see chapter „Contact / Technical Service“).

### 1. Details about the unit

Product number \_\_\_\_\_

Serial number \_\_\_\_\_

Reason for repair \_\_\_\_\_

### 2. Has the device been cleaned, decontaminated/sterilized?

Yes \_\_\_\_\_

No \_\_\_\_\_

### 3. Is the unit in a condition which does not represent any health threats for the staff of our service department?

Yes \_\_\_\_\_

No \_\_\_\_\_

if not, which substances has the unit come into contact with?  
\_\_\_\_\_

### 4. Legally binding declaration

The customer is aware of being legally liable to Heidolph Instruments for any damages arising from incomplete and incorrect information.

Date \_\_\_\_\_

Signature \_\_\_\_\_

Company stamp \_\_\_\_\_

Please note

The shipper is responsible for the return of the goods in well packed condition, suitable for the mode of transport.

### Sender information

Name, first name \_\_\_\_\_

Company \_\_\_\_\_

Department, research group \_\_\_\_\_

Street \_\_\_\_\_

Zip code, city \_\_\_\_\_

Country \_\_\_\_\_

Phone \_\_\_\_\_

E-mail \_\_\_\_\_



MADE IN  
GERMANY

---



01-005-005-47-1, 23.09.2014

© Heidolph Instruments GmbH & Co. KG

This is a translation of the original operating instructions. We reserve the right to make any technical modifications without prior notification. This documentation is not subject to revision; the latest versions of this documentation are found on our homepage. The copyright for all texts and images is held by Heidolph Instruments GmbH & Co. KG.